

ValConnect

Installation manual

Table of contents

1	General.....	3
1.1	System requirements	3
1.2	Software.....	3
2	Installation.....	4
2.1	ValConnect.....	4
2.2	Device description library	4

1 General

This document describes the requirements and procedure how to install ValConnect.

1.1 System requirements

Operating system: Windows 10 and Windows 11

Minimum requirements for the hardware

Screen resolution: 1024 pixels times 768 pixels

Disk space: 500 MB

1.2 Software

To install ValConnect you need the following software.

- DVA-SW-001 – ValConnect
- DVA-SW-002 – Device description library (Optional: Only needed for offline installation)

2 Installation

2.1 ValConnect

- a) Unpack the zip file
- b) Run setup.exe and follow the instruction on the screen. Accept the default settings.

ValConnect is now installed and can be started from the “Program Menu”.

2.2 Device description library

The device description library can be automatically installed over the internet or offline.

Auto update

- a) Go to “Help” → “Update ValConnect”
- b) A new Device description library should be available
- c) Press “Update...”

Manual Update

- a) “Advanced” → “Import device description library”
- b) Select the zip file with the device description. (DVA-UM-002)